


WHERE BRIGGS & STRATTON MOTORS ARE MADE

YOUR Model "WA" Gasoline Motor is one of many thousands which are manufactured annually in this modern Briggs & Stratton Factory at Milwaukee, Wisconsin. More small gasoline motors are produced here than in any other single plant in the world. The building is complete with all modern facilities for precision construction, economical production, rigid inspection and thorough testing. Briggs & Stratton gasoline motors, made here, are shipped to all parts of the world because of their established reputation for reliable service under widely varying conditions.

PRINTED
IN
U.S.A.

Form 66467-101-2½



OPERATING MANUAL
and
PARTS LIST
for
BRIGGS & STRATTON
GASOLINE MOTOR

MODEL - WA

IMPORTANT SAFETY INFORMATION AND INSTRUCTIONS FOR ENGINE SELECTION ENGINE INSTALLATION ENGINE OPERATION

In the USA and Canada,
our 24 hour hotline is:

18002333723

Briggs & Stratton Corporation
Milwaukee, Wisconsin 53201

www.briggsandstratton.com

Keep these instructions for future reference.



Before installing and operating this engine read and observe all warnings, cautions and instructions on both sides of this sheet, on the engine, and in the operating & maintenance instructions.

NOTE: This sheet of instructions and safety information is not meant to cover all possible conditions and situations that may occur. Read entire Operating & Maintenance Instructions for this engine AND the instructions for the equipment this engine powers. Failure to follow instructions and safety information could result in serious injury or death.

The safety alert symbol () is used to identify safety information about hazards that can result in personal injury.

A signal word (DANGER, WARNING, or CAUTION) is used with the alert symbol to indicate the likelihood and the potential severity of injury. In addition, a hazard symbol may be used to represent the type of hazard.

 **DANGER** indicates a hazard which, if not avoided, will result in death or serious injury.

 **WARNING** indicates a hazard which, if not avoided, could result in death or serious injury.

 **CAUTION** indicates a hazard which, if not avoided, might result in minor or moderate injury.

CAUTION, when used **without** the alert symbol, indicates a situation that **could result in damage to the engine.**

HAZARD SYMBOLS AND MEANINGS



Fire



Explosion



Moving Parts



Toxic Fumes



Hot Surface



Shock



Kickback

(OVER)

FORM MS-6445-01/03

ENGINE SELECTION

 WARNING

Failure to select the correct engine could result in fire or explosion.

- Some engines are unique and designed for specific applications or types of equipment. If this engine will be used to build new equipment, contact Briggs & Stratton to ensure that the engine is appropriate for the intended use.
Note: For all Go-karts use only a model 136200 series engine, which offers improved safety and performance.
- Replacement engines should be the same model as the original engine, or be the Briggs & Stratton designated replacement engine. Refer to the Operation & Maintenance Instructions for engine identification information.
Note: For all Go-karts use only a model 136200 series engine, which offers improved safety and performance.
- Do not use Briggs & Stratton engines on 3-wheel All-Terrain Vehicles (ATVs), motor bikes, air craft products, or vehicles intended for use in competitive events. Briggs & Stratton does not approve of or authorize such uses.

ENGINE INSTALLATION



- [1] Do not attempt to install this engine if you do not have the appropriate tools and knowledge of small engine installation procedures. Use only Briggs & Stratton parts. Contact your Authorized Service Dealer for assistance.
- [2] Do not modify the engine in any way without Briggs & Stratton factory approval. Any such modification is at the owner's sole risk.
- [3] If the exhaust system on the old engine was supplied by the equipment manufacturer, you must transfer the exhaust system and related components (original muffler and related pipes, brackets, clamps, and shields) to the new engine. All components must be in good condition.
- [4]



 WARNING	Install muffler (and muffler deflector if used) so outlet points away from operator, fuel tank, and equipment, and so muffler heat will not damage or deform engine and components.
	
- [5]



 WARNING	Ensure all fuel lines and fittings are properly assembled and do not leak. Replacement parts must be the same model as the original.
	
- [6]



 WARNING	Ensure all wiring, including safety switches and engine shut-off components are completely installed and functioning properly.
	
- [7] Set engine speed to equipment manufacturer's specification. Refer to equipment manufacturer's manual. Do not tamper with governor springs, or other parts that will increase engine speed above specification.

- [8]







 WARNING	All engine parts, including fuel cap, spark plug, muffler, air cleaner, and covers and guards for drive components (gears, belts, shafts, couplings, etc.) must be in place before attempting to start engine.
	
- [9]

 WARNING	If engine is installed on walk behind lawn mower, all mower components, including cutting blade, must be correctly installed before attempting to start engine.
	
- [10]

 WARNING	When working on the engine or equipment, remove spark plug wire from spark plug. For electric start, remove negative wire from battery.
	
- [11]

 WARNING	Do not check for spark with spark plug removed. Use Briggs & Stratton spark tester #19368.
	

ENGINE OPERATION

	 WARNING
	When adding fuel:
<p>Turn engine off and let engine cool at least 2 minutes before removing gas cap.</p> <p>Fill fuel tank outdoors or in well-ventilated area. Fill tank to about 1 inch below lowest portion of neck to allow for fuel expansion.</p> <p>Keep gasoline away from sparks, open flames, pilot lights, heat, and other ignition sources.</p>	
	 WARNING
	When starting engine:
<p>Remove all external equipment/engine loads.</p> <p>Wait until spilled fuel is evaporated. Start engine outdoors.</p> <p>Pull cord slowly until resistance is felt, then pull rapidly.</p> <p>If engine floods, set choke to OPEN/RUN, place throttle in FAST and crank until engine starts.</p>	
	 WARNING
	When operating equipment:
<p>Do not tip engine or equipment at angle which causes gasoline to spill.</p> <p>Run engine outdoors. Do not run in enclosed area, even if doors or windows are open.</p> <p>Do not choke carburetor to stop engine.</p>	

INDEX

	Paragraph Number	Page Number	Illustration Page Number
Air Cleaner	17, 18	4	
Carbon	61, 65	20, 21	
Carburetor	26, 27, 52 to 59 Incl.	7, 8, 18, 20	7, 18
Adjusting	54 to 57 Incl.	18, 19	7, 18
Choke	26, 27	7, 8	5, 7
Hook-up	53	18	17
Cleaning	58, 59	19, 20	5, 7, 18
Cooling	16, 39	4, 13	
Compression	33, 60 to 62 Incl.	10, 20	
Connecting Rod	66	22	
Cranking	24	7	
Cylinder	65, 67, 68	21, 22	
Gasoline Line (Cleaning)	31	9	
Gasoline Tank	22	6	5
Guarantee	6 to 18 Incl.	2 to 4	2
Governor	49 to 50 Incl.	17	17
Hand Throttle Control	51	17	17
Ignition System	23, 36, 40 to 48 Incl.	6, 7, 13 to 17	9, 14, 16
Contact Points	45	15	16
Fly Wheel	40, 42	14, 15	14
Fly Wheel Key	40, 42	14, 15	14
Spark Plug Cable	47	16	
Spark	28	8	8, 9
Spark Plug	29, 43	8, 9, 15	5, 9
Stop Button	44	15	5
Lubrication System	19 to 21, 38, 39	6, 13	
Fill. Oil Reservoir 13, 14, 19 to 21 Incl.	3, 4, 6		5
Oil to use	19	6	
When to add & change oil 13 to 16 Incl.	3, 4		
Parts			
How to order	23, 24		
Illustrations	25 to 29	25 to 29	
Price List	30 to 38		
Piston	62, 63, 67, 68	20, 21, 22	
Priming Motor	30	9	
Registration Card	6 to 8 Incl.	2, 3	2
Service Stations	39, 40		
Speed Adjustment	49	17	
Starting Motor	24	7	
Stopping Motor	25	7	5
Timing	64	21	21
Trouble Chart	10, 11		
Valves	61	20	

◆ SPECIFICATIONS ◆

Model "WA" Motor

BEARINGS—S. A. E., babbitt lined.

BORE—2¼ inches.

CAMS and GEAR—One piece construction. Cams accurately ground, to operate quietly.

CARBURETOR—Float feed type, adjustable.

CONNECTING ROD—Drop forged Lynite. Large split bearing on crankshaft.

CRANKSHAFT—Drop forged 1045 S. A. E. material and counter balanced to reduce vibration. Bearings large and accurately ground.

CYLINDER and CYLINDER HEAD—L Head, removable. Equipped with large fins for efficient cooling.

GASOLINE CAPACITY—1 gallon.

GOVERNOR—Mechanical type, holds speed automatically at any set point between 1800 and 2400 r. p. m.

IGNITION—High tension magneto, built in flywheel. Moisture and dust proof. Standard 18 M. M. metric spark plug.

LUBRICATION—Splash type. Positive lubrication to all parts from plunger pump driven from cam shaft eccentric.

OIL CAPACITY—3¼ pints.

PISTON—Light weight Lynite, with 2 compression rings and 1 oil control ring.

POWER—1½ h. p. at normal speed 1800 r. p. m. Develops over 1½ h. p., at 2400 r. p. m.

SPEED RANGE—1800 r. p. m. to 2400 r. p. m.

STROKE—3¼ inches.

VALVES—Alloy steel. Stems enclosed and lubricated by oil spray from crankcase.

WEIGHT—105 pounds, complete with throttle controls.

Briggs & Stratton Corporation
Milwaukee, Wis., U. S. A.

Authorized Central Service Stations

(Also see page 39)

STATE	CITY	NAME	LOCATION
California	Los Angeles	Electric Equipment Co., Inc.	1240 So. Hope St.
California	San Francisco	Automotive Service, Inc.	950 Van Ness Ave.
Colorado	Denver	Spitzer Electrical Co.	809 Broadway
Florida	Miami	Electrical Equipment Co.	42 N. W. 4th St.
Georgia	Atlanta	Auto Electric and Magneto Co.	477 Spring St., N. W.
Illinois	Chicago	Motor Service Co.	3300 Indiana Ave.
Indiana	Indianapolis	H. T. Electric Co.	612 N. Capitol Ave.
Iowa	Des Moines	Motor Service Co.	1214 Grand Ave.
Kansas	Wichita	The E. S. Cowie Electric Co.	230 So. Topeka Ave.
Maryland	Baltimore	Parks & Hull, Inc.	1031 Cathedral St.
Massachusetts	Boston	Wm. H. Flaherty Co.	49-52 Cummington St.
Michigan	Detroit	Auto Electric & Service Co.	90 Selden Ave.
Minnesota	Minneapolis	Reinhard Bros. Co., Inc.	11 So. Ninth St.
Missouri	Kansas City	The E. S. Cowie Electric Co.	1819 Wyandotte St.
Missouri	St. Louis	S. G. Hoffman Magneto Co., Inc.	3134 Washington Blvd.
Nebraska	Omaha	Carl A. Anderson, Inc.	1514 Jones St.
New York	Buffalo	The Battery & Starter Co., Inc.	855 Main St.
New York	New York	P. J. Durham Co., Inc.	244 W. 49th St.
North Dakota	Minot	Reinhard Bros. Co., Inc.	24 First St., S. E.
Ohio	Toledo	The Electric Power Maintenance Co.	28-30 Seventeenth St.
Oklahoma	Oklahoma City	J. C. Hamilton Co.	121 West Third St.
Pennsylvania	Philadelphia	Auto Equipment & Service Co., Inc.	1522 Fairmount Ave.
Pennsylvania	Pittsburg	Penn Storage Battery Co.	5534 Penn Ave.
South Dakota	Aberdeen	Reinhard Bros. Co., Inc.	317 So. Lincoln St.
Texas	Amarillo	The E. S. Cowie Electric Co.	213 E. 8th Ave.
Texas	Dallas	Beard & Stone Electric Co., Inc.	701 N. Pearl St.
Texas	Houston	Beard & Stone Electric Co., Inc.	San Jacinto St. & Polk Ave.
Washington	Seattle	Sunset Electric Co.	1530 11th Ave.

CANADIAN CENTRAL SERVICE STATIONS

Manitoba	Winnipeg	Beattie Auto Electric, Ltd.	176 Fort St.
Ontario	Toronto - 5	Auto Electric Service Co., Ltd.	15 Breadalbane St.

Important

When sending motor or parts for service, at the same time always send, by mail, the following information:

Model letter and motor number. (Take from brass plate on motor)

Date purchased.

Dealer purchased from, giving his name, town and state.

Approximate number of hours motor has run.

Name of machine motor is used on.

Also give complete report of trouble experienced and any special servicing instructions. (See Page 39)

The above information is necessary to insure prompt and proper service

This Gasoline Motor Is Your Faithful Friend

Treat it as a Friend

1. This Briggs & Stratton Gasoline Motor embodies the most modern principles of gasoline motor construction. It is made of high-grade materials and is built by skilled craftsmen. Before it left the Briggs & Stratton Factory it was put through many rigid tests, was carefully inspected and found to be in first class condition to give satisfactory service.

2. The less you tinker with the Briggs & Stratton Gasoline Motor the better service it will give you. This does not mean, however, that your motor does not require a certain amount of attention, for it is only a machine. It cannot tell you its wants but depends on you to give it the right kind of fuel, oil and care.

3. This operating manual gives you the following information:

	Pages
About the Guarantee.....	2 to 4
Starting the motor for the first time.....	6, 7
What to do when the motor will not start.....	7 to 10
Trouble Remedy Chart	10, 11
How your motor works	12, 13
Its construction and maintenance	14 to 22
How to order parts.....	23, 24
Parts illustrations	25 to 29
Parts and price lists	30 to 38
Central Service Stations	39, 40
Index	Inside Front Cover
Motor specifications	Inside Back Cover

4. If this instruction book does not help you locate some specific trouble in your motor, then something too serious for you to correct has occurred. This means that it will be best to leave the motor alone and let an expert do the work. Consult your dealer first, he most likely can help you, or will refer you to a nearby authorized Service Station or advise you to return the motor to the Factory.

5. Be sure to read instructions on page 23 on how to order parts for best service.

Have You Sent in the Registration Card Which Brings Your Guarantee Certificate?

6. You are entitled to a ninety day guarantee on your Model "WA" Motor, so be sure that you get the Guarantee Certificate. It will only be sent to you after the Registration Card has been filled in

REGISTRATION CARD
No. _____
To Receive your MOTOR GUARANTEE CERTIFICATE
Model _____ T. No. _____ A. No. _____
Date _____
Your Name _____
Mail Address _____
Town _____
Dealer Purchased From _____
Motor Mounted on _____
Machine No. _____
Briggs & Stratton Corp., Milwaukee, Wis.

GUARANTEE CERTIFICATE
The Original _____ of this Briggs & Stratton Motor
Model _____ T. No. _____ A. No. _____
Date _____
following guarantee:
Briggs & Stratton Corporation will replace for the original found, upon examination at our factory at normal use and service, on account of defects charges on part or parts submitted for re-purchaser
has been the subject of misuse, negligence or side of our Milwaukee factory, or author-ent, affects its condition or operation.
19_____
J. Briggs, President
BRIGGS & STRATTON CORPORATION
#153

Registration Card and
Guarantee Certificate

properly and mailed to the Factory. The dealer from whom you bought your motor should do this for you, but if he did not do so you should complete the card and mail it at once.

7. By mailing in this card you not only make sure of getting your Guarantee Certificate but you also have your name and motor registered at the Briggs & Stratton Factory and with the author-

New Service Information Prompt Service

The Briggs & Stratton Corporation has established in the principal cities of the United States and Canada, Authorized Service Stations to give efficient and prompt service on repairs and parts for all Briggs & Stratton gasoline motors.

Authorized Service Station Facilities

Every Authorized Service Station carries a complete stock of repair parts, is equipped with special Factory tools and has Factory-trained mechanics to give expert repair service.

To Assure the Right Kind of Service

To insure the same quality of service being rendered by each Service Station as at the Factory, all approved methods of making repairs as developed by Briggs & Stratton Factory are immediately supplied to each Authorized Service Station by traveling service men of the Briggs & Stratton Service Department.

Free Replacement of Defective Material and Workmanship

NOTE: The guarantee does not cover free replacement of parts or workmanship because of failure due to wear, misuse, negligence or accident, nor adjustment or maintenance necessarily resulting from operation.

All Authorized Service Stations (see list on page 40) have the authority of the Briggs & Stratton Corp. to make free replacement of **DEFECTIVE MATERIAL OR WORKMANSHIP ONLY** providing the guarantee on the motor is still in effect, and when proper data as listed below is submitted at time of service.

Important

When sending motor or parts for service, at the same time always send, by mail, the following information:

- Model letter and motor number. (Take from brass plate on motor)
- Date purchased.
- Dealer purchased from, giving his name, town and state.
- Approximate number of hours motor has run.
- Name of machine motor is used on.

Also give complete report of trouble experienced and any special servicing instructions.

The above information is necessary to insure prompt and proper service

PARTS AND PRICE LIST

Part No.	Name	Where Used	Price Each
91084	Oil drain plug	Base10
91108	Cap screw (2" long)	1—Cylinder head10
		1—Valve cover	
91109	Cap screw (2½" long)	2—Cylinder head10
91111	Cap screw (3" long)	3—Cylinder head10
91138	Swivel screw	Bell crank assembly05
91152	Plug screw	Carburetor by pass20
91160	Cap screw	2—Carburetor rod05
91162	Cap screw	Connecting rod05
91168	Nut	Carburetor control05
91195	Rd. Hd. Screw	1—Oil tube retainer	
91196	Screw	For throttle spring clip on motors without hand throttle control.....	.05
91212	Screw	Upper half carburetor body05
91213	Cap screw	Carburetor plug05
91215	Screw	Carburetor plug05
91217	Cap screw	Gas tank to crank bracket.....	.10
91229	Cap screw	Gas tank bracket10
91232	Screw	Carburetor throttle adjustment05
91256	Fillister Hd. Screw	Air cleaner elbow05
91281	Lockwasher	3—Magneto plate to crankcase.....	.01
91315	Cap screw 1½" long	1—Crank bracket to crankcase10
91316	Cap screw 2¾" long	1—Crank bracket to crankcase10
91371	Oil filler nipple 2" long.....		.20
91383	Hex. nut	Power take off side—Crankshaft....	.20
91384	Lockwasher	Power take off side—Crankshaft....	.05

ized Central Service Station in your territory so that, should you write regarding service or parts, your requirements will be taken care of promptly.

8. If you did not get a Registration Card, ask your dealer for one or write to the Briggs & Stratton Factory.

What the Guarantee Includes

9. For 90 days from the date of purchase, Briggs & Stratton Corporation will replace for the original purchaser, free of charge, any part or parts found upon examination at our Factory at Milwaukee, Wisconsin, or authorized Briggs and Stratton Service Station, to be defective under normal use and service, on account of defect in material or workmanship. All transportation charges on parts submitted for replacement under this guarantee must be paid by purchaser.

What the Guarantee DOES NOT Include

10. This guarantee does not cover the free replacement of parts, because of wear occasioned by use. It does not cover the labor cost of replacing parts, neither is it effective if the motor has been the subject of misuse, negligence or accidents, nor if the motor has been repaired or altered outside of our Milwaukee Factory or authorized Service Stations in any way which, in our judgment, affects its condition or operation.

Keep Your Motor Clean

11. It is important to keep your motor clean both inside and outside. This extra care will repay you many times in better service.

12. See that no dirt or water enters motor when filling with oil or gasoline. As a precautionary measure always wipe off the gasoline cap and oil filler plug as well as around them before refilling.

Failure to Follow these Instructions Voids Your Guarantee

Put oil in every day

13. A motor which is run without oil will be ruined within a few minutes. To avoid the possibility of such an occurrence, and the

resulting expense this would cause, always fill the oil reservoir to the level of the filler plug opening every five hours motor runs.

Change oil at least once for each twenty five hours motor runs

14. After each twenty five hours of operation, the old oil must be completely drained from the crankcase by removing either one of the oil drain plugs at the base of the motor. One of these can be seen in the motor illustration of Fig. 1 on page 5. Drain out the oil when the motor is hot, as the oil drains out more quickly and thoroughly. Then replace the plug and refill with fresh oil. We do not recommend flushing out with kerosene.

15. In the normal running of any motor small particles of metal from the cylinder walls, pistons and bearings will gradually work into the oil. Dust particles from the air also get into the oil. Sludge forms a gummy mass which clogs up the oil passages. If oil is not changed regularly, these foreign particles cause increased friction and a grinding action which shortens the life of the motor.

16. Fresh oil also assists in cooling, for in an air-cooled motor old oil gradually becomes thick and loses its cooling as well as its lubricating qualities.

Air Cleaner

17. Operating a Briggs & Stratton motor in a dusty or dirty atmosphere without using an air cleaner voids your guarantee, because no motor can stand up under the grinding action that takes place when dirt and sand particles are drawn in through the carburetor.

18. It is necessary to clean the air cleaner occasionally. This can be done by tapping the filter with a wooden stick to shake off the excess dust, or to clean it more thoroughly, the dust may be brushed off with a whiskbroom. Should the felt become oily or greasy it may be washed in high test gasoline and then dried before replacing.

PARTS AND PRICE LIST

Part No.	Name	Where Used	Price Each
69689	Oil filler cap assembly40
69690	Crankcase with gov. crank bushing No. 68483		18.25
69741	Gasoline pipe75
69742	Bell crank assembly20
69743	Governor lever55
90001	Screw	Carburetor throttle and choke shutter	.05
90200	Screw	Carburetor float bowl cover	.05
90366	Lock washer	2—Connecting rod05
		2—Oil pump	
90373	Lock washer	Carburetor vent screw	.05
90449	Cotter pin	Choke shaft	.01
90597	Machine screw	Governor flange	.05
90683	Lock washer 1/2"	Gas tank bracket	.01
90699	Lock washer	2—Carburetor to bracket	.05
90700	Cap screw	Bell crank to crankcase	.05
90766	Lock washer	Carburetor float bowl cover	.05
90802	Cap screw	Carburetor control	.05
90832	Lock washer	4—Governor cover plate	.01
		1—Blower back plate—Governor side	
		1—Oil tube retainer	
		1—Back plate—Magneto side	
		1—Cylinder shield to cylinder head	
		4—Blower case spacer	
90847	Valve tappet lock nut05
90887	Cap screw	4—Crankcase05
		3—Cylinder	
		1—Gas tank to crank bracket	
90890	Cap screw	Valve tappet	.05
90891	Cap screw	1—To hold governor gear in place	.05
90895	Cap screw	1—Gas tank to bracket	.05
90902	Machine screw	3—Magneto plate05
		2—Carburetor	
		4—Governor crankcase cover	
90916	Machine screw	1—Blower back plate—Magneto side	.05
		1—Cylinder shield	
		4—Blower case spacer	
91059	Lockwasher	1—Carburetor upper body	.01

PARTS AND PRICE LIST

Part No.	Name	Where Used	Price Each
69517	Starter gear and bracket assy.	Crank starting equipment	15.00
69518	Starter bracket with oil cup	Crank starting equipment	8.00
69522	Crank starting equipment complete as illustrated		20.00
69545	Crankcase cover assembly complete with bearing and oil sucker		5.35
69547	Oil pump assembly complete with connector No. 63202		2.50
69549	Oil pipe	Oil pump	.65
*69628	Standard piston assembly complete including the following		5.75
	2—No. 65776 Piston pin lock rings		
	1—No. 61237 Oil ring		
	2—No. 68141 Compression rings		
	1—No. 61238 Piston		
	Note—No. 69660 Piston assembly .010" oversize includes		7.25
	1—No. 61253 Piston .010" oversize		5.25
	1—No. 61256 Oil ring .010" oversize		1.00
	2—No. 68331 Compression rings .010" oversize		.50
	2—No. 65776 Piston pin lock rings		.05
	Note—No. 69661 Piston assembly .020" oversize includes		7.25
	1—No. 61254 Piston .020" oversize		5.25
	1—No. 61257 Oil ring .020" oversize		1.00
	2—No. 68341 Compression rings .020" oversize		.50
	2—No. 65776 Piston pin lock rings		.05
	Note—No. 69662 Piston assembly .030" oversize includes		7.25
	1—No. 61255 Piston .030" oversize		5.25
	1—No. 61258 Oil ring .030" oversize		1.00
	2—No. 68351 Compression rings .030" oversize		.50
	2—No. 65776 Piston pin lock rings		.05
69642	Connecting rod assembly—consisting of—		7.50
	2—No. 65852 Shims	2—No. 91162 Screw	
	2—No. 67502 Washer	2—No. 90366 Lockwasher	
69676	Bearing complete with retainer ring and pin—Drive side		1.75
69686	Carburetor		12.50
69687	Crankcase assembly complete—includes—		30.00
	1—No. 69690 Crankcase	1—No. 61164 Cam gear	
	1—No. 66203 Camshaft	2—No. 66193 Cam follower	
	1—No. 65932 Camshaft plug	2—No. 90890 Tappet Screw	
	2—No. 90847 Tappet nuts		

* Before ordering read the NOTE immediately below this part number.




Fig. 1.

Model "WA" Motor

Starting the Motor for the First Time

Use the right kind of oil

19. We recommend the use of GARGOYLE MOBILOIL "ARCTIC" or other high grade oil of similar characteristics having low carbon residue and a body not heavier than S. A. E. No. 20. A grade of heavy oil which might be satisfactory in a tractor or for lubricating farm machinery must NOT be used.

Do not mix oil with the gasoline

20. Do not mix oil with the gasoline. It is not necessary in this 4-cycle motor for it is provided with a complete splash lubrication system which includes a plunger pump operated from an eccentric on cam. This system provides adequate lubrication for all parts of the motor. The oil is also effective in cooling the motor by carrying heat away from the piston and cylinder walls.

Fill the oil reservoir

21. The oil filler opening is in the motor base as shown in the motor illustration of Fig. 1 on page 5. This filler opening may be at either end of base. Remove filler cap and pour in oil until it rises to the level of the filler cap opening. The capacity of the oil reservoir is three and a quarter pints.

Fill the Gasoline Tank

22. The gasoline tank is filled by removing the large gasoline tank cap which is shown in Fig. 1 on page 5. The capacity is one gallon, High Test gasoline is recommended and insures easy starting, particularly in cold weather. Be sure that the small vent hole in the gasoline tank cap is not clogged up, for air must enter the tank to allow the gasoline to flow to the carburetor.

Spark

23. A spark will be supplied to the spark plug as soon as you crank the motor, the source of ignition being a magneto built into the flywheel. You do not need to turn on any switch in order to turn on the ignition.

PARTS AND PRICE LIST

Part No.	Name	Where Used	Price Each
69053	Armature and magneto plate assembly including the following—		8.25
	1—No. 69282 Bearing	1—Oil sucker complete	
	4—No. 37346 Rivets	3—Gaskets. 005-.009 and .015 thick	
69076	Magneto assembly with air guide—Complete as illustrated		12.00
69105	Governor shaft and flange assembly		.40
*69107	Cylinder assembly complete including the following—		25.00
	2—No. 65906 Valve springs		
	2—No. 68283 Valve spring collars		
	2—No. 68293 Valve spring collar retainers		
	1—No. 68553 Exhaust valve		
	1—No. 68563 Intake valve		
	1—No. 69151 Cylinder		
	Note—No. 69110 Cylinder with 2 valves ground in place		24.50
69120	Oil screen housing assembly		.50
69134	Muffler		3.00
69146	Blower case assembly	Magneto side	3.75
69151	Cylinder with valve seats only		21.50
69202	By pass tube	Carburetor	.60
69207	Float—Carburetor		1.00
69217	Upper half of carburetor body with throttle shaft bushing		1.90
69249	Throttle shaft—Carburetor		.60
*69263	Tube assembly with tube at right angles with bracket		.50
	Note—No. 69338 Tube assembly with tube at 15° angle with bracket		.50
69282	Magneto plate bearing complete with Retainer pin and Oil retainer ring		1.25
69298	Gas tank strap with screw		.60
69305	Gasoline tank with cap		6.00
69317	Breather tube assembly		.85
69394	Ignition cable	Magneto	.75
69425	Air cleaner assy complete		5.75
69447	Air filter assembly	Air cleaner assembly	2.50
69450	Wing nut and stem assembly	Air cleaner No. 69425	.50
69458	Governor gear and thrust cup assembly		2.00
69515	Starting crank	Crank starting equipment	2.50
69516	Starter gear and shaft assy	Crank starting equipment	6.25


*Before ordering read the NOTE immediately below this part number.

PARTS AND PRICE LIST

Part No.	Name	Where Used	Price Each
67013	Needle valve adjusting screw	Carburetor	.40
67072	Washer	Contact bracket—Magneto	.05
67206	Crankshaft		13.50
67243	Spacer (7/16" long)	1—Cylinder head	.10
67253	Spacer (7/8" long)	2—Cylinder head	.10
67373	Blower case spacer	4—Blower case to crankcase	.20
67446	Spring	Choke lever—Carburetor	.05
67549	Shut off valve	Gas tank	.90
67502	Washer	2—Connecting rod	.05
67652	Oil sucker valve guide	1—Oil sucker—Magneto	.05
		1—Oil sucker—Crankcase	
67662	Oil sucker	1—Oil sucker—Magneto	.05
		1—Oil sucker—Crankcase	
67753	Washer	Magneto flywheel	.05
67902	Thrust washer	Governor gear	.10
68023	Piston pin		.50
68141	Standard compression ring	See No. 69628 for assembly	.35
68143	Spacer	Bell crank to crankcase	.10
68152	Inlet screen	Carburetor	.10
68182	Spring clip	Motors without hand throttle control	.05
68283	Valve spring retainer collar (2-halves)	Valves	.10
68291	Oil sucker valve housing	1—Oil sucker—Magneto plate	.10
		1—Oil sucker—Crankcase	
68293	Spring retainer	2—Valves	.10
68329	Air guide with stop switch	Magneto	.75
68472	Throttle shutter	Carburetor	.15
68473	Governor crank	Crank case	1.10
68482	Choke shutter	Carburetor	.15
68483	Governor crank bushing		.20
68511	Carburetor bracket		.75
68553	Exhaust valve	Cylinder	2.00
68563	Intake valve	Cylinder	1.00
68641	Cylinder head		3.25
68652	Spark plug wrench		.20
68883	Screw	Inlet connection—Carburetor	.10
68891	Inlet housing	Carburetor	.25

Cranking

24. Hold the choke lever (See Fig. 1 or Fig. 2) in the closed position. (The spring automatically holds the choke open.) This choke lever acts the same as the choke on your automobile. Spin the motor with rope or crank starter (crank starter turns left hand or counter clockwise) and immediately after motor fires, gradually open choke until the motor runs with choke wide open. If motor is



*Fig. 2.
Carburetor*

cold it may slow down or sputter. In this case close the choke again, or nearly close it, for a few seconds. If the motor stops you have probably choked it too much or not enough. You will soon learn to judge the correct operation of the choke lever so that the motor can be quickly started and kept running without difficulty.

24A. You should also remember that very slow cranking will not start the motor because of the fact that the spark is produced by the magneto which requires a certain amount of speed before it produces a spark at the plug.

Stopping Motor

25. To stop motor, press on red stop button until motor stops turning.

What To Do When Motor Will Not Start *The correct use of the choke*

26. With gasoline vapor in the motor, this vapor compressed and a spark at the spark plug, there is not much question about starting the motor. Of course it sometimes happens that the gasoline mixture is not right and will not fire properly. This is perhaps the most common cause of failure to start, particularly in a new motor with which you are not thoroughly familiar.

27. The correct carburetor setting is one which gives a good operating mixture when the motor is hot. Because gasoline does not vaporize so well when cold, it is necessary to operate the choke in order to cut down the amount of air and give a mixture which is approximately correct for starting. Until you become perfectly familiar with your motor, however, you may make the mistake of not choking the motor enough or you may choke it too much so as to get a lot of raw gasoline in the motor. If you have operated the choke while cranking the motor three or four times, try cranking two or three times with the choke lever released. Then, if the trouble was due to choking too much you will find that the motor will start as the excess gasoline is driven out through the exhaust pipe.

Checking the Spark

28. To be sure that you have a spark at the spark plug, you can remove the wire from the plug and hold it within $\frac{1}{8}$ " of any metal part of the motor (See Fig.3). Keep the hand back on the insulated part of the wire so that you will not get a shock. Then crank the motor and see if a spark will jump this $\frac{1}{8}$ " gap. If it does, you will know that the spark is amply strong to jump the small gap at the spark plug when under compression in the motor. This test is




Fig. 3.
Checking Spark

evidence that your entire ignition system is working satisfactorily. If there is no spark, check the various items on the trouble remedy chart, pages 10 and 11, or see your local dealer or nearest Briggs & Stratton Service Station.

Checking Spark Plug

29. It sometimes happens that a spark plug porcelain is

PARTS AND PRICE LIST

Part No.	Name	Where Used	Price Each
65737	Gasket	Float bowl cover10
65747	Gasket	1—Carburetor nozzle05
		1—Carburetor plug screw	
65757	Gasket	Carburetor body05
65776	Piston pin lock	See No. 69628 assembly05
65852	Shim	Connecting rod05
65896	Throttle link	Throttle to governor lever10
65906	Spring	Exhaust or intake valve15
65932	Cam shaft plug	Cam shaft05
65942	Valve cover plate25
66037	.005" Gasket	Magneto05
66047	.009" Gasket	Magneto plate05
66142	Clamp	Ignition cable05
66171	Gas tank bracket		1.15
66176	Spring	Idle adjustment—Carburetor05
66186	Spring	Throttle adjusting screw—Carb....	.10
66193	Cam follower	Crankcase	1.50
66203	Cam shaft	Crankcase50
66229	Gasket	Cylinder head75
66403	Flywheel key	1—Crank shaft—Magneto side05
		1—Crank shaft—Power side	
66451	Starter pulley		1.25
*66606	Control wire 45 $\frac{3}{8}$ " long25
	Note—For other lengths specify required length in inches.		
66679	Magneto flywheel		9.20
*66706	Throttle spring	Governor lever to bell crank.....	.15
	Note—On motors without hand trottle controls, use throttle spring No. 6512615
66739	Oil pump rod assembly	Crankcase40
66773	Nut	Carburetor stuffing box gland15
66813	Screw	Cover vent—Carburetor20
66876	Spring	Starting crank35
66979	Starter rope50
*66996	Control wire casing 40" long.....		.35
	Note—For other lengths specify required length in inches.		

*Before ordering read the NOTE immediately below this part number.

PARTS AND PRICE LIST

Part No.	Name	Where Used	Price Each
63054	Helical starter pinion gear	Hand crank	2.50
63067	Bell crank bushing	Hand throttle control	.05
63165	Pipe plug	Carburetor bowl	.05
63197	Collar	2—Starting crank spring	.20
63198	3/16" Dia. Pin	Starting crank	.05
63199	1/4" Dia. Pin	Starting crank	.05
63202	Oil pipe connector	Oil pump	.50
63207	Pump plunger	Oil pump	.15
63217	Nut	Oil tube to pump	.10
63284	Intake pipe		1.25
63352	Choke lever shaft	Carburetor	.20
63353	Choke lever spacer	Carburetor	.10
65084	Washer (Fibre)	Valve cover plate	.05
65124	Gasket	2—Inlet valve seat—Carburetor	.05
65134	Gasket	Plug to by pass—Carburetor	.05
65167	Insulator (1 1/2" long)	Armature lead—Magneto	.05
*65175	Ground wire 18" long		.10
	Note—No. 65185 Ground wire 6" long		.05
65194	Washer (Bakelite)	Contact bracket—Magneto	.05
65227	Gasket	Cylinder	.15
65237	Gasket	Valve cover plate	.10
65244	Gasket	Inlet connection—Carburetor	.05
65247	Gasket	Base	.45
65257	Gasket	Crankcase—Governor side	.30
65387	Packing	Needle valve stuffing box	.05
65431	Base	Carburetor control assembly	.45
65469	Carburetor control assembly—Standard		1.50
65489	Breaker Arm	Magneto	.75
65499	Gas tank cap with gasket		.60
65589	Carburetor control assembly		1.50
65631	Base	Carburetor control assembly	.45
65607	Oil sucker valve housing gasket—Oil sucker—Crankcase		.05
		Oil sucker—Magneto	
65647	Gasket	Carburetor to bracket	.10
65727	Gasket	Gland to nozzle	.05

*Before ordering read the NOTE immediately below this part number.

cracked or broken so that the spark jumps through from the center electrode to the shell of the spark plug and does not jump at the gap inside of the cylinder (see Figure 4). This, of course, prevents the motor from firing. The simplest way to check a spark plug is to try a new one and you will find it advisable to have a spare plug on hand for testing. If the motor starts with the new plug, then you know that the old one is at fault and should be discarded. The gap at the spark plug should be somewhat less than 1/32" (to be exact, .020").




Fig. 4.
Spark Plug

Priming the Motor

30. On the suction stroke, the motor draws gasoline up through the carburetor, mixes it with air, and feeds a combustible mixture to the cylinder. However, if the magneto produces a good spark and a good spark plug is in the cylinder (set with a gap of .020") and still you cannot start the motor, it is advisable to remove the spark plug and pour in about a half teaspoonful of gasoline. This should run the motor three or four revolutions to show you that it is in operating condition, even if there is no gasoline in the tank and the carburetor is not functioning. Difficulty in the carburetor, however, is extremely unlikely, for the new motor you have was thoroughly tested under its own power and was operating perfectly before it was shipped from the Factory.

Cleaning the Gasoline Line

31. If the motor will run after the cylinder has been primed with gasoline but will not run otherwise, it is possible that the gas feed line to the carburetor is stopped up. Shut off the gasoline by closing the valve at the tank. Then disconnect the gasoline connection at the carburetor (see Fig. 1). Now turn on the gasoline valve at the tank and see if gasoline runs in a good full stream from the open

end of the gasoline line. If it does you know there is no obstruction in this line. If it merely drips out slowly, you know that the line needs cleaning. Disconnect the copper gasoline line at the tank end and blow through it with compressed air if this is available; otherwise, run a flexible wire through the line and then blow through it.

Adjusting Carburetor

32. The carburetor is properly adjusted at the Factory but if you think the adjustment has been tampered with you can adjust it over again in accordance with the instructions given on page 19.

Testing Compression

33. The other essential in having a motor run is to have good compression. You can test this by turning the motor over by hand to make sure there is one point in its rotation where it turns harder than it does at other points. This is due to the upward motion of the piston compressing the fuel mixture. If the flywheel is released, it should rock back and should do this two or three times before the compression all leaks away. If there is no compression, refer to trouble remedy chart on pages 10 and 11.

Trouble Remedy Chart

	See Paragraph Number
A--Fuel	
<i>Motor will not start</i>	
1. Gasoline tank supply.....	22
2. Improper use of choke.....	26-27
3. Gasoline does not reach carburetor.....	22-30-31
4. Improper carburetor adjustment.....	54 to 57
5. Carburetor jet clogged.....	58-59
6. Water in the gasoline.....	12
7. Water frozen in carburetor or gasoline pipe.....	31-58-59
(Extremely cold weather only)	
B--Spark	
1. Plug not functioning properly.....	28-29-43
2. Ignition cable grounded, oil soaked or wet.....	47
3. Magneto not delivering proper spark.....	28-36-41-42-48
a. Contact points are not properly adjusted.....	45

PARTS AND PRICE LIST

Part No.	Name	Where Used	Price Each
13M36	Machine screw	1—Contact bracket—Magneto05
		2—Oil sucker—Magneto side	
		2—Oil sucker—Governor side	
13M47	Machine screw	Condenser—Magneto01
13M50	Insulator (3" long)	Armature lead05
796E	Washer (Fibre)	Contact bracket—Magneto05
37346	Rivet	Magneto to air guide05 Doz.
61034	Float bowl cover	Carburetor25
61069	Choke lever	Carburetor40
61072	Throttle lever	Carburetor30
61073	Carburetor body		4.00
61159	Elbow	Air cleaner No. 69425	1.75
61164	Cam gear		6.00
61237	Oil ring—Standard	Piston assembly No. 6962850
61238	Piston—Standard	Piston assembly No. 69628	4.50
61267	Base		7.00
61269	Gas tank support30
61280	Flywheel	Power take off side	8.00
62041	Cover shell	Air cleaner	1.00
62042	Washer	Air cleaner05
62081	Retainer bracket	Oil tube to cylinder25
62082	Retainer washer	Oil screen housing to base15
62129	Cylinder Shield30
62130	Support bracket	2—Gas tank50
62197	Washer	Carburetor choke shaft05
63008	Spacer (1½" long)	3—Cylinder head10
63031	Plug screw	Carburetor05
63032	Inlet valve seat	Carburetor40
63033	Float lever pin	Carburetor05
63034	Inlet valve	Carburetor25
63035	Screw	Carb. choke and throttle lever lock05
63036	Choke lever stop	Carburetor10
63037	Stuffing box gland.....	Carburetor25
63039	Throttle lever stop	Carburetor10
63043	Nozzle	Carburetor35
63045	Idle adjustment screw	Carburetor25

PARTS AND PRICE LIST

Part No.	Name	Where Used	Price Each
EA101	Cap Screw	2—Oil pump to crankcase	.05
7A39	Lock Washer	1—Governor gear retainer	\$.01
7A61	Lock Washer	4—Crankcase to base	.01
		3—Cylinder to crankcase	
		2—Gas tank to bracket	
7BC	Spark Plug with gasket No. 7B24		.75
7B24	Gasket	Spark plug	.05
7B35	Screw	1—Governor lever	.01
7F22	Lock washer	2—Carburetor bracket to crankcase	.01
7K23	Cotter pin	Carburetor control assembly	.01
7K33	Machine screw	Carburetor control assembly	.05
7K41	Swivel	Carburetor control assembly	.20
7K47	Cotter pin	2—Governor crank	.01
7K68	Spring washer	Carburetor control assembly	.10
7T17	Lock washer	2—Condenser—Magneto	.01
		1—Contact point—Magneto	
		1—Cable clamp—Magneto	
		2—Governor flange—Crankcase	
		2—Oil sucker—Magneto	
		2—Oil sucker—Crankcase	
7W8	Machine screw	1—Cable clamp—Magneto	.01
13A10	Gasket .015" thick	Magneto plate	.05
13A11	Hex. Nut	Magneto Flywheel	.05
13A40	Spring	Oil pump plunger	.10
13B30	Lockwasher	Magneto Flywheel	.01
13K3	Washer	1—Retainer governor gear	.05
		1—Carburetor control assembly	
13K4	Bushing	Carburetor control assembly	.10
13K5	Lever	Carburetor control assembly	.50
13K9	Casing clamp	Carburetor control assembly	.05
13K10	Cap screw	Carburetor control assembly	.05
13ME	Contact bracket	Magneto	.50
13MG	Condenser	Magneto	1.50
13M13	Spring	Breaker arm—Magneto	.05
13M21	Shim (bakelite)	Contact bracket—Magneto	.05
13M22	Clamp	Ignition cable—Magneto	.05

Trouble Remedy Chart

See
Paragraph
Number

- b. Contact points oily or dirty.....45
- c. Magneto plate and coil soaked
with water or oil.....45
- d. Stop button bent, stuck, wet or dirty.....44
- e. Safety flywheel key sheared off.....36-41-42

C--Lack of Power

- 1. Poor compression33-60-61
- 2. Poor spark28-29-41 to 48
- 3. Improver carburetor adjustment54 to 57
- 4. Exhaust pipe or muffler clogged.....69
- 5. Improper valve clearance61
- 6. Air cleaner clogged17-18
- 7. Machine being operated is overloaded70
- 8. Machine being operated needs oiling.....70

D--Overheats

- 1. Oil supply low13-19 to 21
- 2. Oil needs changing—is too thick to
cool engine properly.....14 to 16
- 3. Carbon in cylinder head.....65
- 4. Poor spark28-29-41 to 48
- 5. Machine being driven is overloaded.....70
- 6. Machine being driven needs oiling70

E--Stops

- 1. Gas supply shut off22
- 2. Intermittent spark failure28-29-41 to 48
- 3. Overheated
- 4. Flywheel key sheared—loose flywheel36-41-42

F--Knocks

- 1. Carbon in cylinder head65
- 2. Loose connecting rod4-66
- 3. Worn main bearings4
- 4. Loose flywheel36-41-42
- 5. Lack of oil13
- 6. Defect in connection with machine
being driven70

How Your Model "WA" Motor Works

The 4-Cycle Principle

34. The reliability, economy and ease of starting which characterize your Briggs & Stratton motor are due in part to the fact that it is designed on the 4-cycle principle which is the basis of the design of all automobile motors. In the common term "4-Cycle Motor" we leave out the word "Stroke" for this description as applied to a motor really means that there are four strokes to one cycle, a cycle being a series or round of events.




Fig. 5.
4-Cycle Principle

35. In our 4-cycle motor the events are illustrated in Fig. 5. On the intake stroke (illustration at the left), we have the piston going down, producing a vacuum in the cylinder, thereby drawing fuel up through the carburetor so that the space above the piston becomes filled with combustible gas. During this stroke the intake valve is open. In the next illustration we find the piston coming up on the compression stroke with both valves closed. At the top of the compression stroke a spark occurs at the spark plug, firing the gas. This produces an explosion above the piston which forces it down on the firing stroke. Both valves are closed on the firing stroke. On the next upstroke of the piston, with the exhaust valve open, the burned gas is driven out.

63038 *th. shaft bearing*
PLATE NO. 657—PARTS OF CARBURETOR





PLATE NO. 656—PARTS OF IGNITION SYSTEM



The Ignition

36. The spark which fires the gas in the motor is produced by a high tension magneto including magnets which are built in the fly-wheel. This is a simple self contained system which is very reliable. It also does away with batteries and wiring with the exception of the high tension wire to the spark plug and the single wire which comes out to the red stop button. The magneto contains a condenser, a pair of contact points and rotating magnets cast into the flywheel. These rotating magnets are properly timed in relation to the stationary parts of the magneto by keying the flywheel on the crankshaft.

The Carburetor

37. The carburetor is a device for properly mixing gasoline vapor with air and feeding it in correct amounts to the motor.

The Lubrication

38. The lubrication of your Model "WA" Motor is taken care of by a pump which is operated from an eccentric on the camshaft. This pump forces a stream of oil into the piston and cylinder wall and the movement of the connecting rod then throws oil to all other moving parts of the motor. Oil, which is splashed to the main bearings, is in no danger of leaking out of the motor. Return ducts are provided in which check valves are used. The suction in the crankcase draws oil back into the oil reservoir but pressure in the crankcase cannot reverse the action and force oil out again. Consequently, the motor stays clean and the oil supply is efficiently used.

The Cooling

39. The cylinder is cooled by air as are the cylinders of modern airplane motors. The rotation of the flywheel blows air all around the cylinder which is covered with thin metal fins to help carry heat away from the cylinder walls. As previously mentioned, the cooling is also greatly facilitated by the oil in the motor reservoir. In cooling the motor, however, the light portions of oil are gradually driven off and the oil which remains becomes too heavy to lubricate or cool the motor effectively. This is another reason for frequently changing the oil in the reservoir. See paragraphs 19, 20 and 21.

Construction and Maintenance

Ignition System

40. Removing the Flywheel and Magneto. To inspect the magneto or check up on the contact point setting, it is necessary to remove the flywheel.




Fig. 6.

Magneto Flywheel and Crankshaft Taper

This is done by unscrewing the nut which holds it in place. A right-hand thread is used, so the nut should be turned to the left. It can be started by tapping the wrench handle with a hammer. Then place a block of wood against the end of the crankshaft and strike it to loosen the flywheel. The magneto is removed by taking out three screws.

41. Replacing Magneto. Magneto should be assembled to crankcase with proper gaskets so that end play of crankshaft is not less than .002" or more than .008". When mounting magneto to crankcase, be sure that




Fig. 7.

Tightening Flywheel

the lockwashers are used with the three mounting screws.

PLATE NO. 659—PARTS OF STARTER AND THROTTLE CONTROLS





PLATE NO. 658—PARTS OF CYLINDER AND GAS TANK



42. **Replacing the flywheel.** When completing any necessary work, replace the flywheel, being sure to use the soft flywheel key supplied. The key is only for the purpose of locating the flywheel on the crankshaft in the correct position so that the magneto will be correctly timed. The flywheel is driven, however, by being a tight taper fit on the taper of the crankshaft. (This taper is shown in Figure 6.) In case the flywheel should come loose, the soft key is designed to shear off so that no damage will be done. Therefore, A STEEL KEY SHOULD NEVER BE USED. After the flywheel is in place, has been located with the key and nut or pulley has been screwed up, this nut or pulley should be made VERY TIGHT. This can be done as shown in Fig. 7 by striking the wrench handle or bar with a hammer.

43. **Spark Plug** A sectional view of the spark plug is shown in Fig. 4. The purpose of the porcelain is to prevent the spark from jumping anywhere except at the gap in the cylinder. If the porcelain is cracked or broken, however, the spark may jump through to the shell of the spark plug. This will prevent the motor firing. Water on the outside of the spark plug may permit the high voltage spark current to leak over the surface of the porcelain. Carbon deposits on the porcelain inside of the cylinder will do the same thing. The spark plug should, therefore, be removed to see that the porcelain is not heavily coated with carbon. It can be cleaned by taking the plug apart and washing off the carbon with gasoline or cleaning with some kitchen scouring powder. When the plug has been put together again, the gap should be set at .020".

44. **Stop Button.** See that the stop button is not bent or held down by the blower case so that it makes contact continuously. To check this it may be necessary to remove the blower case. See that the button is not shorted with dirt, water or oil. Also check the small wire which runs down to the magneto to see that it is not grounded.

45. **Contact Points.** While the magneto plate is still on the motor, you can turn the crankshaft by hand and see if the contact points

open and close properly. They should have a gap of .020". Adjustment is made by loosening the contact bracket screw and moving the bracket to its desired position. The surfaces of the contact




Fig. 8.
Contact Points


points should be clean and lined up so that when they come together they make good electrical contact. If points become badly burned or pitted it may be necessary to replace them with new ones. When checking up the contact points be sure that all parts of the magneto are clean and free from grease, water and dirt. Small metal particles, in particular, will cause trouble and prevent the magneto from firing. The various parts can be cleaned with gasoline on a clean rag. Avoid getting gasoline on the coil. Dry off the magneto with

another clean rag before putting it in service again.

46. Inspect the soldered terminal on the condenser and contact bracket.

47. Spark Plug Cable. Check the spark plug cable to see that the insulation is not broken, soaked with oil or water, grounding it, especially at some point where it touches the motor or is very near to the motor. It may be necessary to remove the flywheel and magneto in order to check this cable all the way to the magneto coil. **UNDER NO CIRCUMSTANCES SHOULD THE CABLE BE SOLDERED TO THE COIL** as heat damages the coil insulation. A twisted connection is sufficient as the cable is held securely by a clip. When checking the cable, also check the ground wire which goes up to the red stop button to see that the insulation is not broken so that the wire rubs on some metal part of the motor.

PLATE NO. 655—PARTS OF CRANKCASE



is not safe. By following these suggestions carefully you will avoid delay and added expense usually connected with C. O. D. shipments.

E. Be sure your name and address are given plainly and correctly
Print name and address. Do not abbreviate name of town or state.

F. Always specify on the order how shipment to you is to be made.

G. Address your order or letter to Briggs & Stratton Corporation, Milwaukee, Wisconsin or Authorized Briggs and Stratton, Service Station, attention of Service Department.

H. After you have made out order, check back to see that you have followed these instructions accurately.

This will save time and money for you and assist in giving prompt and efficient service.

I. When returning Motor or Parts to Factory or Service Station.

If your motor or parts are returned for any reason, be sure your name and address are on both the inside and outside of the package.

Mark the crate or package for the Motor Service Department.

You should also write explaining fully the reason for the return and exactly what is to be done with it.

Model and motor number must always be given from which parts were taken, to insure prompt and accurate service.

All return shipments must be prepaid, or they will not be accepted.

PRICES

NOTE—All prices in this book are subject to change without notice. In case of change in price, orders will be filled at current prices. All prices shown are F. O. B. our Factory in Milwaukee, Wis. Prices higher in Canada.

48. **Condenser, Coil and Magnet.** If you have not located the trouble up to this point, it is probably in the condenser, the coil or the magnet. Under these circumstances, you should see your dealer or send in the complete magneto with flywheel to the Briggs & Stratton Factory, or to the nearest Briggs & Stratton Service Station.

Governor

49. **Speed Adjustment.** Normal motor speed 1800 to 2400 R. P. M. To change motor speed, change tension of throttle spring by moving throttle spring clip. More tension on throttle spring increases speed, less tension reduces speed. (See Figure 9).

50. **Resetting Governor Lever.** If governor lever has been loosened on its shaft it is reset as follows; (See Fig. 9). With carburetor attached to motor and hooked up to governor lever with throttle link, loosen clamp screw which holds governor lever on its shaft. Hold upper end of governor lever firmly




Fig. 9.

Carburetor to Governor Hookup

to the right with throttle lever against its stop on carburetor. Holding governor lever in this position, turn governor shaft hard to right or clockwise, with pliers, until you feel it strike a stop inside of crankcase. Tighten clamp screw firmly, being sure that neither the governor shaft nor governor lever moves while doing so.

Hand Throttle Control

51. Model "WA" motors which are equipped with hand throttle controls are hooked up as illustrated in Figure 10. The control casing tube assembly is fastened down with one of the crankcase mounting screws. The control




Fig. 10.

Hand Control Hookup

Model and motor number must be given when writing or ordering parts

casing with the control wire inside is inserted into the tube, with the wire coming through the top. The end of the wire is fastened to the wire swivel on the bell crank. The bell crank is held on the crankcase with the spacer bushing and cap screw. The coiled end of the throttle spring is hooked to the other end of the bell crank, and the long end of the spring is hooked thru the cotter on the governor lever. Pulling on the control wire increases motor speed.

Carburetor

52. The carburetor used on your Model "WA" Motor is shown in Fig. 11. As received from the Factory it is properly adjusted. However, if it has been tampered with, it can be adjusted over again as follows:

53. Hook-up. First make sure that the throttle link has one end hooked through the hole in the top of the governor lever from the outside toward the crankcase and the other end hooked into the hole in the bottom of throttle arm on back of throttle shaft of carburetor (see Figure 9).




Fig. 11.
Carburetor

54. High Speed Adjustment (See Figure 11). Close the needle valve adjusting screw (high-speed adjustment) located on the carburetor, by turning clockwise all the way in (never force the needle against its seat.) Then open the needle valve one and one-half turns.

55. Now close the idle adjustment screw which is located opposite the fuel inlet, by turning clockwise all the way in. Then open it one-half turn. You are now ready to try the adjustments and make

take a garden hose and run water into the open end of the exhaust pipe. If full streams of water come out of the small holes at the end of the muffler, you will know that it is not clogged up. If the water runs through very slowly, however, the muffler is probably clogged and should be replaced with a new one.

Effect of Load on Motor Operation

70. We have covered practically every condition that could possibly affect the operation of your Model "WA" Motor. Of necessity, however we have not been able to touch on conditions in the machine which the motor is driving. It is just as important to check up on the machine as it is to take care of the motor. The machine should not be overloaded, should be lubricated regularly and should be inspected to see that the belt or chain drive is in good condition.

Important

Follow these instructions when ordering parts or when writing for information.

- A. Before ordering parts
Check up with your dealer if it is possible to do so, in regard to parts you believe are needed. He will assist you on any service that is necessary and will help you select the correct parts for your motor.
- B. Give model letters and number of motor
This information is most important as we make many gasoline motors in various types and sizes. You will find the model letters and motor number on the brass plate at the side of the motor.
- C. Give name and catalog number of parts wanted
You will find part numbers and description in section following parts illustrations. (Do not use numbers cast on parts.)
- D. Send remittance with order to cover parts plus postage
Prices of parts are given in the pages which follow. Add what you think will be sufficient for postage and send postal or express money order for this amount. Do not send currency in a letter. It

been removed for the purpose of cleaning carbon or grinding valves, care should be used in replacing it. Use a new gasket if possible. Otherwise, clean the old one and coat both sides with cup grease. We do not recommend the use of shellac on cylinder head gasket. In tightening the six cap screws, tighten them a little at a time so that the cylinder head is pulled down evenly rather than all at one side first.

Connecting Rod

66. The connecting rod is also made of special aluminum alloy which combines strength with light weight. The lower bearing is of conventional type used with splash lubrication, and should it become loose, can be refitted. When assembling connecting rod to crankshaft, the oil hole as shown in Figure 13 must be toward the magneto. When replacing the cap the assembling marks must be on the same side as shown in figure 13.




Fig. 13.
Connecting
Rod

Worn or Scored Piston, Rings or Cylinder

67. This will only occur after long use of the motor, unless it was run without oil, oil not of the quality and grade recommended, oil not changed regularly, or run with continuous overload.
68. When diameter of cylinder at center is .005" or more, larger than diameter of cylinder at the ends (top and bottom), cylinders should be reground to necessary standard oversize, which is .010", .020", or .030" as required and fitted with the corresponding standard oversize piston and rings. An authorized Briggs & Stratton Service Station should make the repairs.

Exhaust Pipe and Muffler

69. After long periods of service it is possible that the muffler will become clogged to the point where it will affect the motor's power. To check the muffler you can unscrew it from the motor,

the final adjustment of the carburetor. Before doing so, however, run the motor until it is thoroughly warmed up. Then turn the needle valve adjusting screw clockwise until the motor sputters or the speed begins to drop. Then open the needle valve again by turning it counter-clockwise until the motor operates smoothly.

56. **Idling Adjustment.** Set the throttle lever to desired idling speed by adjusting throttle lever adjustment screw. At this idling speed make idle adjustment by first turning the adjusting screw counter-clockwise and then turning it clockwise until the motor operates smoothly when idling. Any change in the throttle lever stop screw will require a new idling adjustment.

57. **Final Adjustment.** With motor again running at normal full speed recheck the operation of the highspeed adjustment. Also test adjustments by accelerating from idling to high speed. The best final adjustment is one in which you get smooth running and good power with the needle valve adjusting screw turned clockwise as far as possible. When the final carburetor setting has been determined, do not change it again. This final setting will take care of starting and running although during particularly cold weather you may have to operate the choke a little more than usual while the motor is warming up.

58. **Cleaning the Carburetor.** The carburetor will seldom require cleaning although it sometimes happens that a speck of dust or lint will get into one of the small openings and affect the carburetor's operation. Removing the fuel inlet screw and disconnecting the gasoline line from the carburetor permits removing the inlet connection. When you do this, you will find a cylindrical screen which can be taken off and washed in gasoline. If the carburetor continually floods or leaks, it is probable that there is dirt in the inlet valve. To check this, it is best to have the carburetor off. You can then turn the carburetor upside down and loosen the inlet valve seat. Inverting the carburetor while taking out the seat is advisable so that the inlet valve itself will not fall into the float chamber. When the valve and seat have been taken out they can be inspected

or washed in gasoline to make sure there is nothing to interfere with the proper seating of this valve.

59. **Cleaning the Nozzles.** With the carburetor off, you can remove the needle valve adjusting screw by unscrewing the nut in which it is mounted. This nut is called a stuffing box gland. You can also take out the plug screw. Looking into these two openings you will now see two very small holes or jets. These should be cleaned by blowing out with compressed air. The nozzles in which these holes are drilled can also be unscrewed and washed in gasoline or the holes can be cleaned by running a fine SOFT wire from a shipping tag through them. The use of the wire, however, is not recommended as it may damage the nozzle or affect the size of the opening which is very carefully calibrated.

Compression

60. Compression in the motor is obtained by having valves which seat properly, gaskets which are tight, a spark plug which does not leak, and piston and piston rings which are properly fitted.

61. **Valves.** The valves are properly fitted when the motor comes from the factory. The exhaust valve marked "EX" is of special material, designed to withstand high temperatures. Its seat is a steel ring pressed into the cylinder block. This construction is better practice than merely facing a seat in the cylinder block itself. It is included in the construction details of your Model "WA" Motor, however, because of the increased satisfaction it gives. After long periods of use, the valves should be ground in, just as you would grind valves in an automobile motor. In working on the valves it is best to remove the muffler and exhaust pipe, also the carburetor and intake pipe shown in Fig. 1. Removal of the valve cover plate then gives access to the valve adjustments. The clearance on the intake and exhaust valves to be .006". These adjustments are made with the motor cold.

62. **Piston.** The piston in the Model "WA" Motor is made of a special aluminum alloy which is very light in weight. This material per-

mits your motor to develop maximum power at high speed, with minimum vibration. The standard clearance between the piston and cylinder wall is .0055" to .007". The piston rings, when fitted into the cylinder, should have from .007" to .012" gap.


63. **Piston Pin.** The piston pin is a push fit in one side of the piston and a force fit in the other. To remove this pin without special equipment, it is advisable to heat the piston in boiling water. Cut a wooden pin a little smaller than the size of the piston pin and use this and a hammer to drive the pin out. You should of course drive the pin out while the piston is still hot. The piston should also be heated up in order to enable you to easily replace the pin. The heating facilitates the work because of the rapid expansion of aluminum when heated. This also accounts for the clearance of .0055" to .007" which is used in fitting the piston to the cylinder.

Timing

64. The timing of the valves is taken care of by the meshing of the camshaft gear with the one on the crankshaft. These gears are properly meshed when the two punch marks on the gears come together as shown in Fig. 12.

Cylinder Head

65. The cylinder head is held on with six cap screws. The longest screws go at the part of the cylinder head where the fins are the highest. Tubular spacers are also used with the screws. When the cylinder head has



*Fig. 12.
Timing*