Parts Manual

Mfg. No: 10H902-0117-E1

Copyright © Briggs & Stratton. All Rights reserved

16-Apr-2024

Model Components

	Page
Air Cleaner, Exhaust System	4
Blower Housing/Shrouds, Flywheel, Rewind Starter	6
Brake, Controls, Governor Spring, Ignition	8
Camshaft, Crankcase Cover/Sump, Crankshaft, Piston/Rings/Connecting Rod	10
Carburetor, Fuel Supply	12
Cylinder, Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Lubrication, Operator's Manual, Warning	14
Replacement Engine - US & Canada	18

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Air Cleaner, Exhaust System

Mfg. No: 10H902-0117-E1











Not for Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Air Cleaner, Exhaust System

REF NO	PART NO	QTY	DESCRIPTION
81	691179		LOCK, Muffler Screw
163	271139S		GASKET, Air Cleaner -(Air Cleaner)
300	692307		MUFFLER -(Super Lo Tone)
534	691417		SCREW -(Air Cleaner)
535	698369		FILTER, Air Cleaner Foam
536	698472		CLEANER, Air
613	691413		SCREW -(Muffler)
836	690664		SCREW -(Muffler Guard)
883	691880		GASKET-EXHAUST

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Blower Housing/Shrouds, Flywheel, Rewind Starter

Mfg. No: 10H902-0117-E1

1036 EMISSIONS LABEL





















Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Blower Housing/Shrouds, Flywheel, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
23	795549		FLYWHEEL
37A	691209		GUARD-FLYWHEEL -(Muffler Side)
37B	690482		GUARD, Flywheel -(Carburetor Side)
55	692144		HOUSING, Rewind Starter
58	697316		ROPE, Starter -(88 5/8)
60	691915		GRIP, Starter Rope
65	690837		SCREW -(Rewind Starter)
73	699850		SCREEN, Rotating
78	692198		SCREW -(Flywheel Guard)
304	694051		HOUSING-BLOWER -(Non Compliance Engines)
305	692198		SCREW -(Blower Housing)
332	690662		NUT -(Flywheel)
363	19069		PULLER, Flywheel
455	691236		CUP, Flywheel
456	692299		PLATE-PAWL FRICTION
459	281505S		PAWL-RATCHET
592	690800		NUT -(Rewind Starter)
597	691696		SCREW -(Pawl Friction Plate)
608	499706		STARTER, Rewind
689	691855		SPRING-FRICTION
921A	793973		HOUSING, Blower
969	694046		SCREW -(Blower Housing) (2 1/3)
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1210	499901		PULLEY/SPRING ASSY -(Pulley)
1211	499901		PULLEY/SPRING ASSY -(Spring)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Brake, Controls, Governor Spring, Ignition

Mfg. No: 10H902-0117-E1

























Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Brake, Controls, Governor Spring, Ignition

REF NO	PART NO	QTY	DESCRIPTION
24	222698S		KEY, Flywheel
188	692198		SCREW -(Control Bracket)
201	690347		LINK, Air Vane
209	690251		SPRING-GOVERNOR -(Yellow)
211	691859		SPRING, Governed Idle
222	691445		BRACKET-CONTROL
265A	691024		CLAMP, Casing
267	691044		SCREW -(Casing Clamp)
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing)
271	691028		LEVER, Control
333	793281		ARMATURE, Magneto
334	691061		SCREW -(Magneto Armature) (1" Long)
335	691107		SCREW -(Magneto Armature With Air Vane) (1 15/16)
356	692390		WIRE, Stop
621	692310		SWITCH, Stop
635	66538S		BOOT, Spark PLug
668	692889		SPACER
729	690586		CLIP, Wire
745	691146		SCREW -(Brake) (7/8)
745A	690859		SCREW -(Brake) (1/2)
772	691111		SCREW -(Linkage Cover)
851	493880S		TERMINAL-SPARK PLUG
922	692135		SPRING, Brake

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Mfg. No: 10H902-0117-E1



Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Camshaft, Crankcase Cover/Sump, Crankshaft, Piston/Rings/Connecting Rod

REF NO	PART NO	QTY	DESCRIPTION
4	698691		SUMP, Engine
12	692218		GASKET, Crankcase -(.015)(Standard)
15	691680		PLUG, Oil Drain
16	691471		CRANKSHAFT
22	692551		SCREW -(Crankcase Cover/Sump)
24	222698S		KEY, Flywheel
25	790908		PISTON ASSEMBLY -(Standard) -Used After Code Date 04111400
25	792532		PISTON ASSEMBLY -(.020 Oversize) -Used After Code Date 04111400
25	699657		PISTON ASSEMBLY -(Standard) -Used Before Code Date 04111500
26	795132		SET, Ring -(Standard) -Used After Code Date 04111400
26	795134		SET, Ring -(.020 Oversize) -Used After Code Date 04111400
26	699658		SET, Ring -(Standard) -Used Before Code Date 04111500
27	691588		LOCK, Piston Pin
28	298909		PIN. Piston -(Standard) -Used Before Code Date 03100100
28	699659		PIN, Piston -(Standard) -Used After Code Date 03093000
28	298908		PIN, Piston -(.005 Oversize) -Used Before Code Date 03100100
29	699654		ROD-CONNECTING
32	691664		SCREW -(Connecting Rod)
33	296676		VALVE, Exhaust -(Grooved Stem-Includes Retainer)
34	296677		VALVE, Intake -(Grooved stem-includes Retainer)
35	690520		SPRING-VALVE -(Intake)
36	690520		SPRING-VALVE -(Exhaust)
40	692194		RETAINER, Valve
43	698690		SLINGER-GOVERNOR/OIL
45	691762		TAPPET, Valve
46	691998		CAMSHAFT
718A	499047		PIN, Locating -(Crankshaft)
741	691805		GEAR, Timing
868	697338		SEAL, Valve

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Carburetor, Fuel Supply

Mfg. No: 10H902-0117-E1



Not For Reproduction

Carburetor, Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
90	795469		CARBURETOR
97	691931		SHAFT, Throttle
106	691901		SEAT, Inlet
130	691190		VALVE, Throttle
163	271139S		GASKET, Air Cleaner -(Air Cleaner)
180	494406		TANK, Fuel -(Metal)
190	691640		SCREW -(Fuel Tank) (1 3/4)
190A	691108		SCREW -(Fuel Tank) (9/16" Long)
365	790029		SCREW -(Carburetor)
390	691839		SPRING-CHOKE DIAPH
393	691837		SCREEN, Carburetor
394	795083		DIAPHRAGM, Carburetor
529	692189		GROMMET
612	496046S		TUBE-PICK UP
617	270344S		SEAL, O-Ring -(Intake Manifold)
633	691321		SEAL-CHOKE/THR SHAFT -(Throttle)
670	691633		SPACER, Fuel Tank
724	697478		RETAINER, Seal
913	494409		SEAT, Valve
957	497929S		CAP, Fuel Tank -(Plastic)
976	694394		PRIMER-CARBURETOR

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Cylinder, Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Lubrication, Operator's

Mfg. No: 10H902-0117-E1

1058 OPERATOR'S MANUAL



1330 REPAIR MANUAL



1319 WARNING LABEL



***REQUIRED** when replacing parts with warning labels affixed.*

358 ENGINE GASKET SET







1095 VALVE GASKET SET











Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Cylinder, Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Lubrication, Operator's

REF NO	PART NO	QTY	DESCRIPTION
1	699653		CYLINDER ASSEMBLY
2	399269		KIT, Bushing/Seal -(Magneto Side)
3	299819S		SEAL, Oil -(Magneto Side)
5	790169		HEAD, Cylinder
7	698717		GASKET-CYL HD
8	791781		BREATHER ASSEMBLY
9	695890		GASKET-BREATHER
10	691666		SCREW -(Breather Assembly)
11	691245		TUBE, Breather
12	692218		GASKET, Crankcase -(.015)(Standard)
13	691640		SCREW -(Cylinder Head)
20	391483S		SEAL, Oil -(PTO Side)
50	699644		MANIFOLD, Intake
51	699649		GASKET, Intake
54	691111		SCREW -(Intake Manifold)
163	271139S		GASKET, Air Cleaner -(Air Cleaner)
200	691912		BLADE, Governor
287	691002		SCREW -(Dipstick Tube)
306	690400		SHIELD, Cylinder
307	690345		SCREW -(Cylinder Shield)
337	697451		PLUG, Spark
358	794209		GASKET SET, Engine
383	89838S		WRENCH-SPARK PLUG
426	691107		SCREW -(Governor Blade)
523	692040		DIPSTICK
524	691876		SEAL, O-Ring
525	691320		TUBE, Dipstick
529	692189		GROMMET
635	66538S		BOOT, Spark PLug
668	692889		SPACER
718	690959		PIN, Locating -(Cylinder)
745	691146		SCREW -(Brake) (7/8)
842	691870		SEAL, O-Ring -(Dipstick Tube)
847	691440		DIPSTICK/TUBE ASSY
869	699641		SEAT, Valve -(Intake)
870	699642		SEAT, Valve -(Exhaust)
871	63709		BUSHING, Valve Guide -(Intake)
871	699643		BUSHING, Valve Guide -(Exhaust)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Cylinder, Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Lubrication, Operator's

Mfg. No: 10H902-0117-E1

1058 OPERATOR'S MANUAL



1330 REPAIR MANUAL



1319 WARNING LABEL



***REQUIRED** when replacing parts with warning labels affixed.*

358 ENGINE GASKET SET







1095 VALVE GASKET SET











Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Cylinder, Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Lubrication, Operator's

REF NO	PART NO	QTY	DESCRIPTION
883	691880		GASKET-EXHAUST
1058	277038		MANUAL, Operator's
1095	498526		GASKET SET, Valve
1319	794467		LABEL, Warning
1330	270962		REP MAN-1 CYL L-HD

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
	10T8020016	1	Replacement Engine
	398211	1	Replacement Short Block
	-----		Top No-Load Speed: 3100 -Trim: ALL
	-----		Service Note: Replacement engine listed is not available in the State of California. Repair with Short Block and individual parts.
	-----		Service Note: Transfer Muffler and/or Spark Arrester Assembly from the original engine if suitable for additional service or add new parts as required

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Copyright © Briggs & Stratton. All Rights reserved