



# Parts Manual


Mfg. No: 11P902-0127-B1



---

<b>Model Components</b>	<b>Page</b>
Air Cleaner.....	4
Alternator, Electric Starter, Ignition.....	6
Blower Housing, Cover/Guards, Flywheel, Rewind Starter.....	8
Camshaft, Crankshaft, Cylinder, Operator's Manual, Piston/Rings/Connecting Rod, Warning Label.....	10
Carburetor, Carburetor Overhaul Kit.....	12
Controls, Governor Spring, Thermostat.....	14
Cylinder Head, Gasket Set-Valves, Valves.....	16
Exhaust System.....	18
Fuel Supply, Lubrication.....	20
Gasket Set-Engine, Sump.....	22
Replacement Engine - US & Canada.....	24


Not For  
Reproduction



## Air Cleaner


REF NO	PART NO	QTY	DESCRIPTION
11	796478		TUBE, Breather
163	691894		GASKET, Air Cleaner -(Air Cleaner)
265	690798		CLAMP, Casing
267	691044		SCREW -(Casing Clamp)
347	795333		SWITCH, Rocker
445	795066		FILTER, A/C Cartridge
497	691044		SCREW -(Stopswitch Bracket)
627	796702		BRACKET, Stopswitch
875	796492		BASE, Air Cleaner -(Plastic)
967	796254		FILTER, Pre Cleaner
968	796493		COVER, Air Cleaner
971	690349		SCREW -(Air Cleaner Base to Carburetor)

Not For Reproduction



## Alternator, Electric Starter, Ignition

REF NO	PART NO	QTY	DESCRIPTION
333	796500		ARMATURE, Magneto
334	793454		SCREW -(Magneto Armature)
337	692051		PLUG, Spark
347	795333		SWITCH, Rocker
356B	692602		WIRE-STOP
356C	695630		WIRE, Stop
365	793458		SCREW -(Carburetor)
383	19576S		WRENCH, Spark Plug
621	692310		SWITCH, Stop
627	796702		BRACKET, Stopswitch
635	66538S		BOOT, Spark PLug
697	691127		SCREW -(Drive Cap)
742	93941		RETAINER, E Ring
851	493880S		TERMINAL-SPARK PLUG
853A	695897		ADAPTER, Wire
910	796498		STUD -(Alternator)
1119	794100		SCREW -(Alternator)
1212	796537		STUD -(Blower Housing)
1212B	797002		STUD -(Blower Housing) (Used With Alternator Only)





## Blower Housing, Cover/Guards, Flywheel, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
23B	796621		FLYWHEEL -(Cast Iron)
37	590921		GUARD, Flywheel
37A	796534		GUARD, Flywheel
58	697316		ROPE, Starter
60	281434S		GRIP, Starter Rope
60A	799716		GRIP, Starter Rope
75	691736		WASHER -(Flywheel)
78	793480		SCREW -(Flywheel Guard)
304	796692		HOUSING, Blower -(Rewind Start)
332	690662		NUT -(Flywheel)
363	19069		PULLER, Flywheel
455	796615		CUP, Flywheel
608	796497		STARTER, Rewind
668A	797383		SPACER
925	796531		COVER, Linkage
1005	796614		FAN, Flywheel
1212	796537		STUD -(Blower Housing)
1212A	793479		STUD -(Blower Housing)
1212B	797002		STUD -(Blower Housing) (Used With Alternator Only)
1335	793481		NUT -(Blower Housing)

1319 WARNING LABEL

**REQUIRED** when replacing parts with warning labels affixed.








1319A WARNING LABEL

**REQUIRED** when replacing parts with warning labels affixed.

1058 OPERATOR'S MANUAL

1036 EMISSIONS LABEL


1330 REPAIR MANUAL



Not For Reproduction

## Camshaft, Crankshaft, Cylinder, Operator's Manual, Piston/Rings/Connecting Rod,


REF NO	PART NO	QTY	DESCRIPTION
1	798948		CYLINDER ASSEMBLY
3	299819S		SEAL, Oil -(Magneto Side)
16	796467		CRANKSHAFT
24	222698S		KEY, Flywheel
25	796644		PISTON ASSEMBLY -(.020 Oversize)
25	796643		PISTON ASSEMBLY -(Standard)
26	796646		SET, Ring -(.020 Oversize)
26	796645		SET, Ring -(Standard)
27	691588		LOCK, Piston Pin
28	298909		PIN, Piston
29	796470		ROD, Connecting
32	691664		SCREW -(Connecting Rod)
32A	695759		SCREW -(Connecting Rod)
43	796650		SLINGER, Governor/Oil
46	694039		CAMSHAFT
404	690272		WASHER -(Governor Crank)
615	690340		RETAINER, Governor Shaft
616	798327		CRANK, Governor
718	690959		PIN, Locating
741	797521		GEAR, Timing
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1058	279946		MANUAL, Operator's
1263	697124		REED, Breather
1264	793453		SCREW -(Breather Reed)
1319	794467		LABEL, Warning
1319A	797669		LABEL, Warning
1330	279000		MANUAL, Repair
1375	796476		COVER, Breather Reed
1376	794451		SCREW -(Breather/Reed Cover)
1430	796477		GASKET, Breather/Reed



Not For  
Reproduction

## Carburetor, Carburetor Overhaul Kit



REF NO	PART NO	QTY	DESCRIPTION
51	796596		GASKET, Intake
51A	590398		GASKET, Intake
104	797622		PIN-FLOAT HINGE
117	697355		JET, Main -(Standard)
118	494870		JET, Main -(High Altitude)
121	796612		KIT, Carburetor Overhaul
122	796595		SPACER, Carburetor
125	796608		CARBURETOR
133	398187		FLOAT-CARBURETOR
134	398188		KIT-NEEDLE/SEAT
137	796610		GASKET, Float Bowl
163	691894		GASKET, Air Cleaner -(Air Cleaner)
202	796657		LINK, Mechanical Governor
216	796485		LINK, Choke
217	798900		SPRING, Choke Return
276	271716		WASHER-SEALING
365	793458		SCREW -(Carburetor)
623	793628		SEAL, O-Ring -(Carburetor Spacer)
975	796611		BOWL, Float



Not For  
Reproduction

## Controls, Governor Spring, Thermostat






REF NO	PART NO	QTY	DESCRIPTION
202	796657		LINK, Mechanical Governor
209	793604		SPRING, Governor
216	796485		LINK, Choke
222	796482		BRACKET, Control -(Manual Friction, Remote, & Fixed Speed Control)
227	796487		LEVER, Governor Control
265	690798		CLAMP, Casing
267	691044		SCREW -(Casing Clamp)
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing)
271	691028		LEVER, Control
291	796486		THERMOSTAT
505	793515		NUT -(Governor Control Lever)
562	793514		BOLT -(Governor Lever)
621	692310		SWITCH, Stop
745	793491		SCREW -(Brake)
883	793497		GASKET, Exhaust
883A	796677		GASKET, Exhaust
922	692135		SPRING, Brake
923	796635		BRAKE





## Cylinder Head, Gasket Set-Valves, Valves

REF NO	PART NO	QTY	DESCRIPTION
5	796471		HEAD, Cylinder
7	796475		GASKET, Cylinder Head
13	799277		SCREW -(Cylinder Head)
33	499642		VALVE, Exhaust
34	795443		VALVE, Intake
35	691304		SPRING, Valve -(Intake)
36	691304		SPRING, Valve -(Exhaust)
40	692194		RETAINER, Valve
45	690977		TAPPET, Valve
51	796596		GASKET, Intake
163	691894		GASKET, Air Cleaner -(Air Cleaner)
192	796631		ADJUSTER, Rocker Arm
238	691300		CAP, Valve
337	692051		PLUG, Spark
383	19576S		WRENCH, Spark Plug
623	793628		SEAL, O-Ring -(Carburetor Spacer)
635	66538S		BOOT, Spark PLug
718	690959		PIN, Locating
830	796472		STUD, Rocker Arm -(Rocker Arm)
868	795440		SEAL-VALVE
883	793497		GASKET, Exhaust
883A	796677		GASKET, Exhaust
886	799492		KIT, Cylinder Head/Plate Gasket
914	794451		SCREW -(Rocker Cover)
993	796473		GASKET, Cylinder Head Plate
1022	796480		GASKET, Rocker Cover
1023	796479		COVER, Rocker
1026	796481		ROD, Push
1029	691230		ARM, Rocker
1034	691343		GUIDE-PUSH ROD
1095	799496		GASKET SET, Valve









Not For  
Reproduction

## Exhaust System


REF NO	PART NO	QTY	DESCRIPTION
81	691740		LOCK, Muffler Screw
300	796495		MUFFLER
613	796496		SCREW -(Muffler)
676	692010		DEFLECTOR, Muffler
676A	799187		DEFLECTOR, Muffler
677	690661		SCREW -(Muffler Deflector)
832	796494		GUARD, Muffler
836	793500		SCREW -(Muffler Guard)
883	793497		GASKET, Exhaust
883A	796677		GASKET, Exhaust
994	690813		ARRESTOR, Spark

Not For Reproduction



## Fuel Supply, Lubrication

REF NO	PART NO	QTY	DESCRIPTION
187	791766		LINE, Fuel -(Cut To Required Length)
187A	796491		LINE, Fuel -(Formed Hose)
240	298090S		FILTER, Fuel
523	796503		DIPSTICK
524	692296		SEAL-DIPSTICK TUBE -(Dipstick Tube)
525	796502		TUBE, Dipstick
601	791850		CLAMP, Hose
670	793485		SPACER, Fuel Tank
842	691031		SEAL, O-Ring -(Dipstick Tube)
847	796501		DIPSTICK/TUBE ASSEMBLY
957	799585		CAP, Fuel Tank -(Plastic)
957A	692046		CAP, Fuel Tank -(Plastic)
957C	796577		CAP-FUEL TANK -(Plastic)
972	590949		TANK, Fuel -(Plastic)
1059	793471		KIT, Screw/Washer



## Gasket Set-Engine, Sump

REF NO	PART NO	QTY	DESCRIPTION
3	299819S		SEAL, Oil -(Magneto Side)
4	493279		SUMP, Engine
7	796475		GASKET, Cylinder Head
12	692232		GASKET, Crankcase
15	691680		PLUG, Oil Drain -(Square Socket)
20	399781S		SEAL, Oil -(PTO Side)
22	691092		SCREW -(Crankcase Cover/Sump)
51	796596		GASKET, Intake
163	691894		GASKET, Air Cleaner -(Air Cleaner)
358	799495		GASKET SET, Engine
524	692296		SEAL-DIPSTICK TUBE -(Dipstick Tube)
623	793628		SEAL, O-Ring -(Carburetor Spacer)
718	690959		PIN, Locating
842	691031		SEAL, O-Ring -(Dipstick Tube)
868	795440		SEAL-VALVE
883	793497		GASKET, Exhaust
883A	796677		GASKET, Exhaust
993	796473		GASKET, Cylinder Head Plate
1022	796480		GASKET, Rocker Cover
1430	796477		GASKET, Breather/Reed

## Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
	121S022022	1	Replacement Engine
	798772	1	Replacement Short Block
	-----		Top No-Load Speed: 3200 -Trim: ALL
	-----		Service Note: Transfer Muffler and/or Spark Arrester Assembly from the original engine if suitable for additional service or add new parts as required

Not For Reproduction



