




Parts Manual

Mfg. No: 19J137-0008-F1



Model Components	Page
Alternator, Controls, Electrical Starter, Governor Spring, Ignition.....	4
Blower Housing, Flywheel, Rewind Starter.....	6
Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/Rings/Connecting	8
Carburetor.....	12
Cylinder Head, Gasket Sets.....	14
Exhaust System, Fuel Supply.....	16
Replacement Engine - US & Canada.....	18
Shrouds.....	19

Not For
Reproduction



Alternator, Controls, Electrical Starter, Governor Spring, Ignition


REF NO	PART NO	QTY	DESCRIPTION
98	593104		KIT, Idle Speed -(High Speed Adjustment)
188	798618		SCREW -(Control Bracket)
202	591834		LINK, Mechanical Governor
209	593657		SPRING, Governor
211	799927		SPRING, Governed Idle
222A	593666		BRACKET, Control
232	797809		SPRING, Governor Link
265	691024		CLAMP, Casing
267	699492		SCREW -(Casing Clamp)
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing)
271	691028		LEVER, Control
309A	593683		MOTOR, Starter
318	799814		SCREW -(Mounting Bracket)
318A	799846		SCREW -(Mounting Bracket)
333A	798616		ARMATURE, Magneto
334	797655		SCREW -(Magneto Armature)
337	696202		PLUG, Spark
356	799789		WIRE, Stop
367	798618		SCREW -(Wire Clip)
383	19576S		WRENCH, Spark Plug
474	591094		ALTERNATOR
485	695755		KNOB, Control
493B	691177		BRACKET, Mounting
493D	593682		BRACKET, Mounting
501	698315		REGULATOR
526	690297		SCREW -(Regulator)
635A	797685		BOOT, Spark Plug
729	797750		CLIP, Wire
729C	593137		CLIP, Wire
813	590392		CLAMP
1009	797795		SCREW -(Starter Motor)
1119	799845		SCREW -(Alternator)



Blower Housing, Flywheel, Rewind Starter


REF NO	PART NO	QTY	DESCRIPTION
23	593139		FLYWHEEL
58	691921		ROPE, Starter -(Cut To Required Length)
65	799923		SCREW -(Rewind Starter)
304	593672		HOUSING, Blower
305	798618		SCREW -(Blower Housing)
332	797811		NUT -(Flywheel)
363	19203		PULLER, Flywheel
455	591820		CUP, Flywheel
458	699334		GRIP, Starter Rope
608	593668		STARTER, Rewind
1005	591789		FAN, Flywheel

Not For Reproduction



Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/


REF NO	PART NO	QTY	DESCRIPTION
1	593663		CYLINDER ASSEMBLY
3	591794		SEAL, Oil -(Magneto Side)
12A	592597		GASKET, Crankcase
15	797793		PLUG, Oil Drain
16	593691		CRANKSHAFT
17	591792		BEARING, Ball -(Crankshaft)
18C	593661		COVER, Crankcase -(Includes Governor Gear - Not Serviced Separately)
20	591793		SEAL, Oil -(PTO Side) (PTO Side)
22	797776		SCREW -(Crankcase Cover/Sump)
22A	593107		SCREW -(Crankcase Cover/Sump)
24	797812		KEY, Flywheel
25	592613		PISTON ASSEMBLY -(Standard)
25	593109		PISTON ASSEMBLY -(.020" Oversize)
25	593108		PISTON ASSEMBLY -(.010" Oversize)
26	593111		SET, Ring -(.020" Oversize)
26	592614		SET, Ring -(Standard)
26	593110		SET, Ring -(.010" Oversize)
27	592044		LOCK, Piston Pin
28	592045		PIN, Piston
29	592046		ROD, Connecting
45	797786		TAPPET, Valve
46	592617		CAMSHAFT
227	592616		LEVER, Governor Control
287	798618		SCREW -(Dipstick Tube)
306B	593680		SHIELD, Cylinder
307	798618		SCREW -(Cylinder Shield)
505	690939		NUT -(Governor Control Lever)
512	591863		HOSE, Oil Drain
522	799941		PLUG, Dipstick/Fill
562	797230		BOLT -(Governor Control Lever)
614	797229		PIN, Cotter
616	592615		CRANK, Governor
631	797794		WASHER -(Oil Drain Plug)
718	797792		PIN, Locating -(Cylinder Head)
718A	797761		PIN, Locating -(Crankcase Cover)
729	797750		CLIP, Wire
842	797327		SEAL, O-Ring -(Dipstick Tube)



Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/





REF NO	PART NO	QTY	DESCRIPTION
847	593174		DIPSTICK/TUBE ASSEMBLY
1026	591818		ROD, Push
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1319	794467		LABEL, Warning
1319A	797669		LABEL, Warning

Not For Reproduction










Carburetor

REF NO	PART NO	QTY	DESCRIPTION
51	591779		GASKET, Intake
51A	591798		GASKET, Intake
53	591801		STUD -(Carburetor)
109	593178		SHAFT, Choke
117	593675		JET, Main -(Standard)
118	590452		JET, Main -(High Altitude)
121C	592229		KIT, Carburetor Overhaul
122	591797		SPACER, Carburetor
125E	593674		CARBURETOR
163	797756		GASKET, Air Cleaner
610	799805		ARRESTOR, Intake
654	690939		NUT -(Carburetor)
711	798618		SCREW -(Carburetor Shield)
996A	593179		SHIELD, Carburetor



Cylinder Head, Gasket Sets

REF NO	PART NO	QTY	DESCRIPTION
3	591794		SEAL, Oil -(Magneto Side)
5	593093		HEAD, Cylinder
7A	592834		GASKET, Cylinder Head
12A	592597		GASKET, Crankcase
13	797791		SCREW -(Cylinder Head)
20	591793		SEAL, Oil -(PTO Side) (PTO Side)
33	592612		VALVE, Exhaust
34	592611		VALVE, Intake
35	591814		SPRING, Valve -(Intake)
36	591814		SPRING, Valve -(Exhaust)
40A	797782		RETAINER, Valve
40C	591816		RETAINER, Valve
40B	591815		RETAINER, Valve
45	797786		TAPPET, Valve
51	591779		GASKET, Intake
51A	591798		GASKET, Intake
163	797756		GASKET, Air Cleaner
238	591817		CAP, Valve
276	797847		WASHER, Sealing -(Rocker Cover)
358	593112		GASKET SET, Engine
718	797792		PIN, Locating -(Cylinder Head)
830	591088		STUD, Rocker Arm
842	797327		SEAL, O-Ring -(Dipstick Tube)
868	797854		SEAL, Valve -(Intake)
883	797770		GASKET, Exhaust
883A	799797		GASKET, Exhaust
914	797848		SCREW -(Rocker Cover)
1022	797846		GASKET, Rocker Cover
1023	799778		COVER, Rocker
1026	591818		ROD, Push
1029	591087		ARM, Rocker
1034	591819		GUIDE, Push Rod
1095	593113		GASKET SET, Valve




Exhaust System, Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
187E	593671		LINE, Fuel -(Formed Hose)
187F	593670		LINE, Fuel -(Formed Hose)
190	590997		SCREW -(Fuel Tank)
300E	593186		MUFFLER
436	799796		MANIFOLD, Exhaust
529	799933		GROMMET -(Fuel Tank)
601	791850		CLAMP, Hose
705	590965		NUT -(Fuel Tank)
832D	593187		GUARD, Muffler
836A	798976		SCREW -(Muffler Guard)
883	797770		GASKET, Exhaust
883A	799797		GASKET, Exhaust
957	794641		CAP, Fuel Tank
958A	593171		VALVE, Fuel Shut Off
972	593170		TANK, Fuel
1177	590965		NUT -(Muffler)
1302	590457		WASHER -(Muffler Guard)
1509	797346		OUTLET, Tank

Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
	19J1370008	1	Replacement Engine

Not For Reproduction



Shrouds

REF NO	PART NO	QTY	DESCRIPTION
281C	593677		HOOD, Snow
287	798618		SCREW -(Dipstick Tube)
307	798618		SCREW -(Cylinder Shield)
472C	791948		KNOB, Choke Shaft
528	799918		HOSE, Primer
654	690939		NUT -(Carburetor)
663	799846		SCREW -(Control Panel)
711	798618		SCREW -(Carburetor Shield)
731D	593679		HOOD, Snow
731E	593678		HOOD, Snow
847	593174		DIPSTICK/TUBE ASSEMBLY
892	798182		SWITCH, Key
976	793382		PRIMER-CARBURETOR
990A	798177		SET, Key
996A	593179		SHIELD, Carburetor
1196A	799919		SCREW -(Snow Hood)

